

PA760 Single Slot Cradle



Package

Please make sure the following contents are in the gift box.

If something is missing or damaged, please contact your unitech representative.

The basic package contents

- PA760 Single Slot Cradle
- Detachable Part
- Adapter

Quick Start Guide

How to charge the PA760 terminal on the single slot cradle

There are two options to charge the PA760 terminal:

- You can directly charge PA760 with bumper case on and slide it into the cradle.
- To charge PA760 without bumper case, please install this detachable part into the cradle before charging.

Here is the detachable part from the cradle:



Alternatively, slide the battery pack into the rear slot of the cradle.





How to install the detachable part

Please put the detachable part toward the LED indications. Then put down the detachable part into the cradle until it clicks into place.



How to remove the detachable part

There are two hooks on each side of the cradle.



Use your thumb to lift up to take out the detachable part. Once it got unhooked, you can lift it up from both sides.



LED Indicator Status

| When the cradle is under standby mode: | |
|--|--|
| Blue LED | Power is on |
| When battery is charging: | |
| Red LED Blue LED | Battery is being charged in rear slot Battery charging is completed |
| When PA760 is inserted in the cradle, the LED indicator on the cradle will not be changed. The charging status is indicated by the LED of PA760: | |
| Red LED Green LED | PA760 is being charged PA760 charging is completed |

CAUTION! • To ensure the unit working properly, please keep all connectors away from the contaminants staying inside of them such as dust, grease, mud, and water. The negligence may cause the unit with no communication, short circuited, overheated and so on.

• If the connector is damaged, please ensure the connector is being fully repaired before using the unit to avoid causing short circuited.

http://www.ute.com/